


Audio Connector : F_AUDIO

The audio connector supports HD Audio standard. It provides the Front Audio output choice.




Audio Connector : CD_IN

CD_IN is a Sony standard audio connector, it can be connected to a CD/DVD-ROM drive through a CD/DVD audio cable.




Floppy Disk Drive Connector : FLOPPY

This motherboard includes a standard floppy disk drive (FDD) connector, supporting 360KB, 720KB, 1.2MB, 1.44MB, and 2.88MB FDDs.



Speaker Connector : SPEAKER

The speaker connector is used to connect speaker of the chassis.



USB Connectors : F_USB1/2

In addition to the four USB ports on the rear panel, this product also provides two 10-pin USB headers on its motherboard. By connecting through USB cables with them, user can quickly expand another four USB ports on the front panel.

